

DOL2108 Instructions

1. Normal time mode

During startup, the normal time is displayed as am12:00 in 12 hour system.

Time setting

In the normal state, press the set key to enter the setting of time and date, and set them respectively in the following order. The setting is completed through the cooperation of adj key.

→ hour → minute → year → month → day → exit

- Setting range: year 2000 ~ 2099, month 1 ~ 12, day 1 ~ 31, hour 1 ~ 12 or 0 ~ 23, minute 0 ~ 59.
- While setting the date, the week (from Monday to Sunday) will change automatically accordingly.
- In the setting state, you can also press the mode key or no key for 1 minute to exit the setting and display the currently set time.

12 / 24 mode conversion

In the normal state, press the adj key for 12 and 24-hour mode conversion.

2. Alarm clock and snooze mode

In the normal state, press the mode key to enter the alarm mode.

Alarm setting

In the alarm mode, press the set key to enter the setting, and set them respectively in the following order. The setting is completed through the cooperation of the adj key.

→ hour → minute → sleepy → music → exit

- In the setting state, you can also press the mode key or no key for 1 minute to exit the setting and display the currently set time.
- In the alarm state, use the adj key to turn on / off the alarm and the sign of sleepiness.

→ (·) → (·) & SNOOZE → OFF

- When the alarm clock reaches the set time, it will sound for 1 minute, and the backlight will be on for 5 seconds; When the snooze interval reaches, it will sound twice, and the backlight will be on for 1 minute each time.
- When the alarm rings or sleepy, press set to stop the alarm or press other keys to pause.
- Interval duration setting of sleepiness: 1 ~ 60 minutes. There are 7 world famous songs and 2 different "didi" sounds to choose from;
- When the alarm and sleepy sign are not turned on, the alarm and sleepy are turned off at the same time. The sleepy function is effective only when the alarm sign is turned on.

3. Timer mode

In any state, press the timer key to enter the timer mode, and the start time of reverse timing is displayed at 23:59 (default time).

Timer set

In the timer state, press the set key to enter the setting, and set them respectively in the following order. The setting is completed through the cooperation of the adj key.

→ Timer status → hour setting → minute setting → second setting

- Setting range: 23 ~ 0 for hours, 59 ~ 0 for minutes and 59 ~ 0 for seconds.
- In the setting state, you can also press the timer key or no key for 1 minute to exit its setting.
- After the above settings are completed, press the timer key to start timing: the currently set seconds begin to decrease. When the timing reaches 0 seconds, the set minutes begin to decrease. When the timing reaches 0 minutes, the same set hours begin to decrease. When the timer reaches 00:00, it will sound for 1 minute, and the backlight will be on for 5 seconds. (if it is currently in timer status, 00:00 on the screen will flash for 1 minute)
- During timing, if you press the timer key repeatedly, the timing will pause / continue. In the timing pause state, press the adj key to clear and set to zero.

4. Luminous mode

Press the light key to turn on or off the night light function. When the light is on, if there is no key operation, it will turn off automatically after a delay of about 5 seconds.